

Primor Level 5 - Quick start

1 Notes on safety

- Due to security reasons change the factory code of 1 2 3 4 5 6 immediately.
- For your new code, do not use any personal data like birthdays or any other data, which could be known by knowledge of your person.
- Simple codes that can be guessed easily i.e. 1 2 3 4 5 6 must not be used.
- Your code has to be secret.
- Don't write down your code.
- Don't save your code on your PC, a DVD, a USB-stick or your mobile.
- Change your code frequently for example every three months.
- After entering the new code, the electronic lock should be opened and locked several times with the safe door opened.
- After each locking doublecheck if the safe is closed.

1.1 Notes on safety emergency lock

- Due to security reasons it is recommended not to leave the key unattended in the lock.
- Don't store the key in the safe.
- The keys have to be stored at a safe place and may only be accessible by authorised persons.
- When losing the key exchange the lock immediately.
- Make sure after each locking if the safe is locked.

Detailed installation/operating instructions are available for download on our website carl-wittkopp.com.

2 Opening

1. Enter your 6-digit code. (Factory master code 1 2 3 4 5 6).
2. Turn the handle within 3 seconds into opening position.

3 Locking

1. Close the door at the safe and turn the handle into locking position.

4 Programming the user code

The master is able to program the user code, but not vice versa.

1. Press and hold the key "1" until the red LEDs flash permanently.
2. Enter your 6-digit **master code**.
3. Enter the new 6-digit **user code**.
4. Re-enter the new 6-digit **user code**.

5 Changing the master or user code

1. Press and hold the key "0" until the red LEDs flash permanently.
2. Enter your **old** 6-digit code.
3. Enter your **new** 6-digit code.
4. Re-enter your **new** 6-digit code.