BURG WÄCHTER

# GUARDIANS
FOR YOUR HOME.

Smart Home from BURG-WÄCHTER: With BURGprotect™, secure your home easily and conveniently.

BURGprotect™

SECURIT

CONVEN

CONTRO

View the brand new BURGprotect™ film.

Y

IIENCE

OL

What drives us is your everyday security!
The BURGprotect™ Smart Home system combines protection against break-in, fire and water damage. During product development, we placed particular importance on convenience. You can install all the components in just a few steps. The alarm system can be expanded at any time and adapted to a new home environment, ensuring everything is always under control.

This is how BURGprotect™ works

Base 2200: Control centre & alarm siren all in one.
The Base 2200 central control unit is the centrepiece of BURGprotect™. All Smart Home components are connected to the alarm control unit. Adding a new component is quick & easy – or more precisely, at the touch of a button. You just scan the printed QR code with your smartphone and the motion detector, window contact or smoke detector is registered, and your alarm system is ready to go. It couldn't be simpler or faster!

The Base 2200 is the centrepiece of our Smart Home system. The control centre manages all the BURGprotect™ sensors and also serves as an alarm siren.

If uninvited guests attempt to break into your home, smoke is detected or a window is opened, the Base 2200 will let you know in a matter of seconds via a push message on your smartphone. At the same time, the unit will trigger an alarm of up to 100 decibels. Only an internet connection is required to use the system. Advantage: The control unit has three possible types of internet access: LAN, WLAN (WiFi) or GSM (SIM card). In addition, the Base 2200 is protected against jammers.

A strong team.

BURGprotect™ offers endless possibilities for your personal Smart Home. Any combination of sensors and components can be combined – this is the key principle of BURGprotect™.

The Starter Set 2200 includes the Base alarm control centre, two Contact 2030 door/window contacts, a Motion 2010 motion detector and the Control 2110

Starter package Set 2200 – your ideal entry into the world of Smart Home! With the Base alarm control centre, two contact detectors, a movement detector and a remote control, you will significantly increase the security of your home.

remote control. With the Starter Set, you can safeguard many areas of your home. For example, the movement detector could monitor the living room, and the contact detector can respond to undesirable movements at patio windows or the front door. The handy remote control can arm your Smart Home at the touch of a button or deactivate it. Ideal for those who don't always have their smartphone on hand.

Everything from one source.

Everything in sight, everything under control: with the free BURGprotect™ app for iOS and Android, you link all the Smart Home components to the Base control unit. Managing the devices via the BURGprotect™ app is clear and simple – no matter whether you install 5, 50, or 200 sensors, such as a movement detector, alarm siren or smoke detector. Intuitive and user-friendly operation was the top priority when the app was developed!

No matter where you are, with the app you can arm the alarm system or unlock it. A false alarm is prevented by using the time delay of the Coming Home and Leaving Home function. Sophisticated features such as the scenario control of the Plug 2140 wireless remote socket will deter intruders. Lamps and TVs are switched on and off as if you were at home.

With the Home function, previously defined sensors remain active. For example, your garage or patio is monitored even when you are home. The Smoke 2050 smoke detector and Water 2060 water detector warn around the clock against possible property damage, for example by a smoking oven or overflowing washing machine.

No matter where you are: With the BURG-protect™ app, you can arm the alarm system or deactivate it. The scenario function of the Plug wireless remote socket is also controlled via the app.

Free for iOS and Android:
you can download the BURGprotect™ app at your particular store.

Your secure Smart Home.

Control panel
If your smartphone isn't handy, take over control of BURGprotect™ with Keypad 2100. Installing the wall mount next to the front door has proven to be effective.

Remote control
With the handy Control 2110, easily control the most important functions of BURGprotect™ with the touch of a button.

Wireless remote socket
Make it look like someone is home. The Plug 2140 socket insert lets you switch on TVs or lamps and simulate your presence.

Movement detector
If uninvited guests are in the house, they will be detected by the Sensor Motion 2010. This will result in an alarm signal and push message.

Contact detector
If intruders pry open windows or a door, the magnetic connection on the Contact 2030 sensor will be broken. The alarm will sound and you will receive a push message.

Front door, windows, living room, patio, bedrooms:
Find out where which BURGprotect™ sensor is used.
From the siren at the front door to the contact detector
on the window and the smoke detector in the living room
and bedrooms.

Water detector
An incident of water
damage occurs every
30 seconds in Germany.
The Water 2060 sensor
detects water penetration
and water overflow
(washing machine).

Vibration detector
Distinctive vibrations
result when windows
or doors are pried open.
The Vibrancy 2020
sensor registers them
and sounds the alarm.

Smoke detector
Fire can be devastating to
your home. The Smoke
2050 sensor warns with
an alarm of up to 85
decibels when there is
smoke present.

Control centre
The Base control unit
is the centrepiece of
BURGprotect™ and at
the same time an alarm
unit with a maximum of
100 decibels.

Alarm siren
Visibly mounted, an alarm
siren will deter potential
intruders. At the same
time, the 2150 Siren will
sound the alarm with a
maximum of 120 decibels
in an emergency.

The BURGprotect™

Starter Set 2200

- Perfect starter set for your home
- Consisting of: 1x Base,
  2x Contact, 1x Motion, 1x Control
- Safeguarding windows and doors,
  the motion detector detects
  intruders

Motion 2010

- Passive infrared detector
- Coverage approx. 110 degrees
- Small animal recognition prevents
 false alarms

Contact 2030

- Contact detector, alarm when
  windows or doors are opened
- Easy installation without screws
- Wide reach

Water 2060

- Water detector, alarm when
  water level is too high
- Can be used to detect
  water penetration and overflow
- Signal when battery is low

™ product world.

Control 2110

• Handy remote control

• Alarm system on/off,
  home scenario on/off

• SOS panic function
  (contact persons are alerted)

Siren 2115

• Acoustic and visual
  alarm signal up to 120 dB

• Deterrence thanks to visible
  exterior installation

• Emergency power battery,
  manipulation protection

Base 2200

• Central control unit with
  integrated siren (max. 100 dB)

• Emergency power battery,
  manipulation protection

• Easy sensor integration
  using QR code

Vibrancy 2020

• Vibration alarm

• Versatile use (window panes,
  furniture, display cases)

• Easy installation without screws

Continued from previous page.

Smoke 2050

- Alarm of up to 85 dB in case smoke is detected
- Can also be used without app
- Signal when battery is low
- EN 14604: 2005

Keypad 2100

- Remote control with touch operated keys for wall installation
- Alarm system on/off, home scenario on/off, SOS panic function (contact persons are alerted)
- LED display of alarm status

Plug 2140

- Socket insert up to 2500 watts
- Can be switched manually or via app
- Ideal for scenario control (lamps, TVs)

BURGprotect App

- Free app for iOS and Android
- Secure thanks to 256 bit encryption
- Intuitive set-up of alarm system

BURGprotect™

Smart Home
BURGprotect™

BURG-WÄCHTER KG
Altenhofer Weg 15|58300 Wetter
Germany

Telephone: +49 (0) 23 35 965 30
Fax: +49 (0) 23 35 965 390
Email: export@burg.biz

BURGprotect Prospekt EN

0418

4 003482 818534

www.burg.biz